

## SELECTION & SPECIFICATION DATA

<b>Generic Type</b>	Fast curing, low temp, concrete repair mortar
<b>Description</b>	This fast-curing epoxy mortar is designed for easy application even in low temperature environments.
<b>Typical Uses</b>	<ul style="list-style-type: none"> <li>• Freezer Floors</li> <li>• Pulp and Paper Mills</li> <li>• Dike Areas</li> <li>• Chemical Storage</li> <li>• Truck Unloading Platforms</li> <li>• Warehouse Floors</li> <li>• Aisleways</li> </ul>
<b>Primer</b>	For installation above 50F - Use the included Steri-Prime. Do not allow primer to puddle. Steri-Flor Fast Patch mortar can be applied immediately over the wet primer. For installations below 50F - Steri-Flor Fast Patch may be used direct to concrete. Prime the repair area using Steri-Flor Fast patch neat resin, then immediately install the mixed Fast Patch mortar over the wet primer.
<b>Solid(s) Content</b>	100% solids
<b>VOC Value(s)</b>	4 g/L
<b>Chemical Resistance</b>	Steri-Flor Fast Patch provides a broad range of resistance to acidic and caustic chemicals, including organic and inorganic substances, oils and salts.  Can withstand 150°F continuous dry heat with excursions of up to 200°F

## SUBSTRATES & SURFACE PREPARATION

<b>Concrete</b>	Concrete must be prepared mechanically to remove surface laitance. Oils, grease and other contaminant must be removed prior to surface preparation. Concrete must be free of curing compounds and form release agents. Surface texture should be similar to 40-60 grit sandpaper or the visual standard, CSP-5 from the International Concrete Repair Institute with exposed pea gravel. The prepared surface should have a nominal tensile strength of 250 PSI per ASTM D-4541.
<b>Metal</b>	Metal surfaces such as equipment bases, sole plates, oil pans, braces or leveling feet which the grout will rest on, or be embedded in, must be free of grease, oil, rust and scale. Where maximum adhesion is required, the contact areas should be abrasive-blasted to a white metal finish to achieve a minimum 2.0 mil profile.  Metal surfaces which are not to be bonded to should be masked or waxed with a generous coat of good quality automotive or floor paste wax.

# Steri-Flor Fast Patch

PRODUCT DATA SHEET



## PERFORMANCE DATA

All test data was generated under laboratory conditions. Field testing results may vary.

Test Method	Results
Bond Strength to Concrete ASTM D7234	Greater than cohesive strength of concrete
Compressive Strength ASTM C579	10,000 PSI
Flame Spread ASTM D635	<5 mm / Self Extinguishing
Flexural Strength ASTM D4060	5,000 PSI
Taber Abrasion ASTM D4060, CS-17 Wheel, 1000 Rev	60 mg
Tensile Strength ASTM C307	2,800 PSI
Water Vapor Transmission ASTM E96	.0018 Perms/in.

## MIXING & THINNING

<b>Mixing</b>	Thoroughly blend Part A with Part B before adding the aggregate. Add EA-1 Aggregate and mix 2-3 minutes or until a uniform consistency is achieved.
<b>Ratio</b>	Steri-Prime: 1:1 Steri-Floor Fast Patch: 2:1 + 30lbs EA-1

## APPLICATION EQUIPMENT GUIDELINES

Listed below are general equipment guidelines for the application of this product. Job site conditions may require modifications to these guidelines to achieve the desired results.

<b>Application Procedure</b>	Trowel into place and finish the surface with S-30 Smoothing liquid. Lifts should be limited between a 1/2" minimum to 2" maximum.
------------------------------	------------------------------------------------------------------------------------------------------------------------------------

## APPLICATION CONDITIONS

Condition	Material	Surface	Ambient	Humidity
Minimum	50°F (10°C)	35°F (2°C)	35°F (2°C)	0%
Maximum	80°F (27°C)	110°F (43°C)	110°F (43°C)	90%
Optimum	70°F (21°C)	75°F (24°C)	75°F (24°C)	50%

Substrate temperature must be 5°F above the Dew Point.

## CURING SCHEDULE

Surface Temp.	Pot Life	Minimum Recoat Time	Maximum Recoat Time	Ultimate Physical Characteristics
35°F (2°C)	30 Minutes	16 Hours	36 Hours	6 Days
50°F (10°C)	25 Minutes	8 Hours	24 Hours	4 Days
70°F (21°C)	20 Minutes	3 Hours	16 Hours	2 Days

## CLEANUP & SAFETY

**Cleanup** | Use S-10 Cleaning Solvent, MEK, or Acetone to clean tools and equipment.

**Safety** | Read and follow all caution statements on this product data sheet and on the SDS. Employ normal safety precautions. Keep container closed when not in use.

## CLEANUP & SAFETY

<b>Ventilation</b>	Ventilation must be used during and after application until the coating is cured. The ventilation system should be capable of preventing the solvent vapor concentration from reaching the lower explosion limit for the solvents used. User should test and monitor exposure levels to insure all personnel are below guidelines. Use MSHA/NIOSH approved air respirators as needed.
<b>Caution</b>	Fire and explosion hazards: This product contains less than 1% volatile components, however, vapors are heavier than air and can travel long distances, ignite and flash back. Eliminate all Ignitions sources. Keep away from sparks and open flames. All electrical equipment and installations should be made and grounded in accordance with the National Electric Code. In areas where explosion hazards exist, workers should be required to use non-ferrous tools and wear conductive and non-sparking shoes.

## PACKAGING, HANDLING & STORAGE

<b>Packaging</b>	<p><b>.3 c/f unit:</b>  <i>Packaged together in a plastic 5 gallon pail</i>  <b>Steri-Prime</b>          Part A: .06 gal (in a pint can)          Part B: .06 gal (in a pint can)  <b>Steri-Flor Fast Patch</b>          Part A: 0.35 Gallon (in a .5 gal gal plastic pail)          Part B: 0.15 Gallon (in a quart can)          Aggregate 1 x 30lbs bag of EA-1 Yields approximately 1.9 mixed gallons</p>
<b>Shelf Life</b>	<p><b>Steri-Prime</b>          Part A: 12 months          Part B: 12 months  <b>Steri-Flor Fast Patch</b>          Part A: 12 months          Part B: 12 months          EA-1: indefinite if kept dry</p>
<b>Storage</b>	<p>Warning: All Dudick products classified with DOT labels as either white, yellow or red labels must not be mixed or stored together as an explosive reaction can occur.</p> <p>All products should be stored in a cool, dry area away from open flames, sparks or other hazards.</p>

# Steri-Flor Fast Patch

## PRODUCT DATA SHEET



---

### WARRANTY

To the best of our knowledge the technical data contained herein is true and accurate on the date of publication and is subject to change without prior notice. User must contact Carboline to verify correctness before specifying or ordering. No guarantee of accuracy is given or implied. Carboline warrants our products to be free of manufacturing defects in accord with applicable Carboline quality control procedures. THIS WARRANTY IS NOT VALID WHEN THE PRODUCT IS NOT: (1) APPLIED IN ACCORDANCE WITH CARBOLINE'S SPECIFICATIONS, AND/OR (2) PROPERLY STORED, CURED, AND USED UNDER NORMAL OPERATING CONDITIONS. Carboline assumes no responsibility for coverage, performance, injuries, or damages resulting from use of the product. If this product is found not to perform as specified upon inspection by a Carboline representative during the warranty period, Carboline's sole obligation, if any, is to replace the Carboline product(s) proven to be defective or refund the purchase price thereof, at Carboline's sole option. Carboline shall not be liable for any other losses or damages. This warranty excludes (1) labor and costs of labor for the application or removal of any product, and (2) any incidental or consequential damages, whether based on breach of express or implied warranty, negligence, strict liability or any other legal theory. NO OTHER WARRANTY OR GUARANTEE OF ANY KIND IS MADE BY CARBOLINE, EXPRESS OR IMPLIED, STATUTORY, BY OPERATION OF LAW, OR OTHERWISE, INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. All of the trademarks referenced above are the property of Carboline International Corporation unless otherwise indicated. The whole text of this Product Data Sheet, as well as the documents derived from it, have been written in English, and for legal purposes the English version shall prevail.